

Wi-Fi Profile Export, Import & Password Retrieval Guide

1. Exporting Wi-Fi Profiles (Windows)

1. Open Command Prompt as Administrator.
2. Run the following to list all Wi-Fi profiles:
`netsh wlan show profiles`
3. Export a specific Wi-Fi profile including the password:
`netsh wlan export profile name="WiFiName" key=clear folder="C:\\WiFiBackup"`
4. This will generate an XML file in the specified folder.
5. Repeat for any additional networks you want to export.

2. Importing Wi-Fi Profiles (Windows)

1. Place the exported XML file(s) on the new PC.
2. Open Command Prompt as Administrator.
3. Import the profile:
`netsh wlan add profile filename="C:\\WiFiBackup\\WiFiName.xml"`
4. If needed, force connection using:
`netsh wlan connect name="WiFiName"`

3. Finding Saved Wi-Fi Passwords (Windows)

1. Open Command Prompt.
2. List all Wi-Fi profiles:
`netsh wlan show profiles`
3. Retrieve the password for a specific profile:
`netsh wlan show profile name="WiFiName" key=clear`
4. Look under:

Security Settings → Key Content

This is the saved Wi-Fi password.

4. Finding Wi-Fi Passwords on macOS

1. Open Terminal.
2. Run the following to retrieve the password from Keychain:
`security find-generic-password -wa "WiFiName"`
3. You may be prompted for your macOS admin credentials.
4. The password will then be displayed.

5. Exporting Wi-Fi Profiles on macOS (Manual Only)

macOS does not support Wi-Fi profile export through Terminal.

You can manually copy Wi-Fi configuration files:

Path:

`/Library/Preferences/SystemConfiguration/com.apple.airport.preferences.plist`

However, this method is not recommended for migration between different macOS versions.